

Braavos Wireless Charging True Wireless Earbuds

Instruction Manual
7198-63



| 01


Hello! This is your instruction manual, to help create the best possible experience with this cool product.

Safety Precautions:

1. Please follow the rules described in this manual closely to ensure your safety.
2. Before using the earbuds, we would strongly encourage you read this manual.
3. Do not modify, repair or dismantle the earbuds or power bank.
4. Do not use any liquids to clean the products.
5. Do not use the earbuds near water, or intense temperatures.

| 02

Included Contents:



1. Multi-function button/Earbud LED
2. Microphone
3. Ear tips
4. Charging LED
5. Micro-USB input
6. Wireless Charging Receiver



| 03

Charging:

**** The battery isolator on both earbuds need to be removed in order to be charged. Be sure to charge the devices completely before initial use.****

1. Charging the earbuds

- Magnetic contact recharging, once placed into the charging case earbuds will begin to charge automatically.
- The LED light of the case will turn blue, the earbud LED will turn red when charging.
- ** Make sure the earbuds LED turns RED to confirm charging has begun.****
- The LED light on the case and earbuds will turn off when charging is complete.

2. Charging the power case

- Use the Micro-USB cable to connect to an adapter or computer to charge the power case.
- When charging the power case LED will flash Green.

| 04

- Once fully charged, the power case LED will turn solid Green.
- 3. **Wireless Charging the power case**
****Wireless charger is NOT included****
- Place the power case with wireless charging symbol(found on the back of the case)on a wireless charging pad.
- When charging the Power Case LED will flash Green.
- Once fully charged, the Power Case LED will turn solid Green.

Stereo Earbud Usage:

1. **Pairing:** First time
Remove both earbuds from the case, they will begin to auto-pair to each other. You will hear a prompt sound followed by the voice prompt "Pairing".

| 05

Both earbuds will quickly flash red and blue to indicate that they are paired to each other. Now Turn on your mobile devices bluetooth. If done successfully only one "Braavos" pairing name will appear.



2. Search and Pairing

Select "Braavos" from your bluetooth function. When you hear "Device Connected" You've successfully connected to your bluetooth. The earbuds are now ready to be used. Both earbuds will slowly flash Blue to indicate that they are paired to your mobile device. Previously paired earbuds will connect automatically after power ON.

| 06

3. **Power ON:**
Take out your earbuds from the charging case or press and hold the multi-function button for 3 seconds.
4. **Power OFF:**
Place your earbuds back into the charging case or press and hold the multifunction button for 5 seconds. When one earbud is turned off, the other will remain on.

5. Calling

Answer/End Call:

Press the multifunction button once to answer an incoming call, and again to end the call.

Reject a call:

Double press the multifunction button to reject an incoming call.

Redial:

Double press the multifunction button to redial the last number you dialed.

| 07

6. Playing Audio

Play/Pause:

Press the Left/right Earbud multifunction button once to pause, and press again to play.

Next Track:

Press the right earbud multifunction button 3 times to play the next track.

7. Activate Voice Assistant:

Press the left earbud multifunction button 3 times, you will hear a beeping sound to indicate that your voice Assistant/Siri is "activated" and awaiting your commands.

Resetting your earbuds:

If having trouble pairing, place the earbuds back to the charging case, it will auto-pair when you take out again.

| 08

Single Earbud Usage:

1. Pairing for the first time

Take out the earbud from charging case, and turn on your mobile devices bluetooth. search "Braavos" & click connecting, it will pair automatically.

2. Power ON/OFF

Power ON: Take out your earbud from the charging case or press and hold the multi-function button for 3 seconds.

Power OFF: Place your earbud back into the charging case or press and hold the multifunction button for 5 seconds.

| 09

Safety Precautions

WARNING—When using this product, basic precautions should always be followed, including the following:

1. Fully read the instructions before using the product.
2. The unit will only achieve full performance after 2 or 3 completed charge and discharge cycles.
3. Do not overcharge your case. The unit may become hot under excessive use. Remove your case once it is fully charged. Never charge your case for more than 7 hours at a time.
4. To reduce the risk of injury, close supervision is required when the product is used near children.
5. Do not expose the device to moisture.
6. Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
7. Do not use the device if damaged or modified.
8. Damaged or modified batteries may exhibit

| 13

3. Once the earbud is successfully connected with your device, you can listen to audio.

4. **Answer/End calls:** Press the multi-button once to answer an incoming call, and again to end.

5. **Reject a call:** Double press the multifunction button to reject an incoming call.

6. **Redial:** Double press the multifunction button to redial the last number you dialed.

7. **Music:** short press the button to pause the music or play the music.

| 10

unpredictable behaviour resulting in fire, explosion or risk of injury.

9. Do not disassemble the device. Take the device to a qualified technician if service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
10. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 212°F/100°C may cause explosion.
11. Have servicing performed by a qualified repair person using only identical replacement parts.
12. This will ensure that the safety of the product is maintained.

FCC Statement

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with the limits for a Class B digital

| 14

Earbud Tech Specifications

Items	Specifications
Charging time	1.5 hrs (from 0-100)
Play time	4 hrs
Bluetooth Range	10m
Mic Sensitivity	-42+3db

Power Case Tech Specifications

Items	Specifications
Charging time	2.5 hrs (from 0-100)

Mobile devices cannot connect with the earbuds if the earbuds are not in pairing mode.

If the earbuds are unable to connect to a mobile device via Bluetooth for 5+ minutes, the earbuds will power off automatically.

| 11

Troubleshooting

Issue	Reason	Solution
Start-up failure	low battery	charge earbuds and power case
No sound when paired	wrong pairing	re-pairing
No indication during charging	Earbuds aren't securely inserted and try again	check earbuds, securely inserted and try again
Shut down automatically	low battery	charge earbuds and power case
Noise during calls	mobile device is too far away	bring mobile device closer
Low volume	earbuds are turned down low	adjust earbuds to comfort & sound
Signal interrupted	environment disturbance, distance to far from mobile device	bring the mobile device closer to the earbuds

| 12

Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

| 15

| 16

FC
MADE IN CHINA

front side

back side