





7122-31

IPWR 10000mAh MagClick Wireless Power Bank and iWatch Charger

Instruction Manual

Whats Included:

- 1 x 10000mAh Magclick Wireless Power Bank



Functions:

1. Integrated Cable with Type-C Tip
2. Power Button
3. Type-C Input/Output Port
4. LED Display
5. USB-A Output
6. Wireless Charging Surface with Magclick
7. iWatch Wireless Charging Surface

Tech Specifications:

1. Capacity: 10000mAh/3.85V/38.5Wh
2. Type-C Input:
DC 5V/3A 9V/2A 12V/1.5A (18W Max.)
3. Type-C Output:
DC 5V/3A 9V/2.22A 12V/1.67A (20W Max.)
4. Type-C Tip Input:
DC 5V/3A 9V/2A 12V/1.5A (18W Max.)
5. Type-C Tip Output:
DC 5V/3A 9V/2.22A 12V/1.67A (20W Max.)
6. USB-A Output:
DC 5V/3A 9V/2A 12V/1.5A (18W Max.)
7. Wireless Output for Phone: 15W Max.
8. Wireless Output for iWatch: 2W Max.
9. Input Power: Certified AC adapter/Computer

Instructions:

1. Charging the Power Bank:

- Be sure the power bank is fully charged before usage.
- Connect the built-in cable with Type-C tip(1) to a USB power source, or use your own Type-C cable and plug it into the Type-C input/output port(3).
- The LED display(4) will show the charging percentage.
- When fully charged, the display will read 100%.

**** Note:** If fast charging is active, the green lightning symbol will appear.

- Disconnect the power bank from the power source once charging is complete.

2. Cable Charging Your Mobile Device:

- Press the Power Button(2) to turn the power bank ON.
- Use the built-in Type-C cable(1) to directly connect to your device or connect your own cable to either the Type-C port 3) or the USB-A port(5) of the power bank.
- Your device will begin charging automatically.
- The LED display will show the remaining battery percentage of the power bank.
- The green lightning symbol will appear when fast charging is supported.
- The power bank will automatically turn off after 35 seconds of inactivity.
- Disconnect your device once it is fully charged.

3. Wireless Charging Your Mobile Device:

- Press the power button(2) to turn on the power bank.
- Place your wireless charging-compatible device on the wireless charging surface(6).
- Charging will start automatically, and the wireless charging icon will appear on the LED display(4).
- Remove your device once fully charged.
- Double press the power button(2) to turn OFF the power bank.

4. Wireless Charging with Magnetic Surface:

- If your phone supports MagSafe, it will securely align with the magnetic charging surface(6).
- The magnetic surface is compatible with other devices, but the magnetic alignment feature will only work with MagSafe-type phones.

**** Note:** When wireless charging, if the GREEN wireless symbol is flashing the device is either NOT a wireless charging device or there is an object between the device and charging surface interfering with the charging process.

5. Charging iWatch with Wireless Charging:

- Press the Power Button(2) to turn the power bank ON.
- Place your Apple Watch on the iWatch wireless charging surface(7).
- Charging will begin automatically.

Safety Precautions:

WARNING-When using this product, basic precautions should always be followed:

1. Read all the instructions before use.
2. Charge the power bank fully before initial use. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
10. Have servicing performed by a qualified repair person using only identical replacement parts.
11. This will ensure that the safety of the product is maintained.
12. Do not overcharge Phone. Unit may get hot with excessive use. Remove Phone when it is fully charged. Never charge for more than 7 hours at a time.
13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.
14. The strong magnetic fields of neodymium Magnets can damage items such as television, Computer monitors, credit cards, bank cards, Computers, diskettes and other data carriers, Video tapes, mechanical watches, hearing aid, loud speakers and VCRs. Pace-makers may be Damaged or switched to "test mode" in the presence of a strong magnetic force, if pacemaker or other electronic body implant is in use, keep a minimum of 3 feet distance.

FCC Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B) / NMB-3 (B)

This Class B digital apparatus complies with Canadian ICES-003.

(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada).

Name of the Distributor:

Leedsworld Inc

Address of the Distributor:

400 Hunt Valley Road,

New Kensington,

PA 15068 USA.

FCC ID: 2A92I-AST-WR318

Model #: AST-WR318

Made in China

