





7143-79

Allcord 5-in-1 Charging Cable with iWatch Charger Instruction Manual

Whats Included:

- 1 x 5-in-1 Charging Cable with iWatch Charger



Functions:

1. USB-A Input Adapter
2. Type-C Input Tip
3. iWatch Charging Surface
4. 2-in-1 Reversible Output Tip
5. Type-C Output Tip
6. Input Tips Storage Slot

Tech Specifications:

1. Input: USB-A and Type-C
2. Output: Type-C and 2-in-1 Reversible
3. Charge Current: 2A
4. Wireless Output for iWatch: 2W

Instructions:

1. Charging Mobile Phones and Other Electronic Devices:

- Retrieve the input tips by sliding them downward and pulling them out from the storage slot (6).
- Connect the USB-A Input Adapter (1) or the Type-C Input Tip (2) to the corresponding input port on a power adapter.
- Make sure that USB-A input adapter(1) is securely connected to the Type-C input tip (2) when using the USB-A tip.
- For mobile phones and other electronic devices, attach the appropriate output tip, either the 2-in-1 Reversible (4) or Type-C (5), to the device's charging port.
- To initiate charging, ensure the connections are secure. The device will start charging automatically once connected properly.

2. Using the 2-in-1 Reversible Tip:

- To use the built-in reversible tip, select the correct orientation of the tip to match your device's charging port:



For **Micro-USB Devices** you will insert the 2-in-1 reversible tip(4) with the 5-PIN side of the cable facing up, as shown to the left.



For **iOS devices** with a lightning port (including iPhone models below 15 series), insert the 2-in-1 reversible tip(4) with the side with no pins facing upwards, as shown to the left.

- Once connected properly, your device will start charging automatically

3. Charging a iWatch:

- Place your iWatch directly on the iWatch Charging Surface (3). Ensure the watch aligns correctly with the charging area to commence charging.
-

Safety Precautions:

WARNING-When using this product, basic precautions should always be followed:

1. Read all the instructions before use.
2. Charge the power bank fully before initial use. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
10. Have servicing performed by a qualified repair person using only identical replacement parts.
11. This will ensure that the safety of the product is maintained.
12. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.
13. The strong magnetic fields of neodymium magnets can damage items such as television, computer monitors, credit cards, bank cards, computers, diskettes and other data carriers, video tapes, mechanical watches, hearing aids, loud speakers and VCRs. Pace-makers may be damaged or switched to "test mode" in the presence of a strong magnetic force, if pace-maker or other electronic body implant is in use, keep a minimum of 3 feet distance.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located for operating in conjunction with any other antenna or transmitter.

Name of the Distributor:

Leedsworld Inc

Address of the Distributor:

400 Hunt Valley Road,

New Kensington,

PA 15068 USA.

Model #: AG0616-B

FCC ID: 2BQZN-AG0616-B

Made in Cambodia