





8053-30

High Sierra 5000 mAh MagStand Wireless Power Bank

Instruction Manual

Whats Included:

- 1 x 5000mAh Magclick Wireless Power Bank
- 1 x 30cm TPE Type-C to Type-C Charging Cable



Functions:

1. Lanyard Hang Hole
2. Type-C Input/Output Port
3. Power Button
4. Magnetic Wireless Charging Surface
5. Built-in Powerbank Stand
6. LED Indicators

Tech Specifications:

1. Capacity: 5000mAh/3.85V/19.25Wh
2. Type-C Input: DC 5V/3A, 9V/2A, 12V/1.5A (18W Max.)
3. Type-C Output: DC 5V/3A, 9V/2.22A, 12V/1.67A (20W Max.)
4. Wireless Output for Phone: 15W Max

Instructions:

1. Charging the Power Bank:

- Be sure the power bank is fully charged before usage.
- Insert the type-C tip of the included cable into a certified AC adapter and the other end into the Type-C Input port(2) to begin charging.
- The LED indicator(6) will flash WHITE when the device is charging and will stop once fully charged.
- ** When the power bank is fast charging there will be a GREEN indicator.
- Once the power bank is fully charged, remove the device from the power source.

2. Cable Charging Your Mobile Device:

- Press the ON/OFF button(3) to turn ON the power bank, then connect your device to the Type-C port(2) using the appropriate cable. Charging will begin automatically.
- LED indicators will glow WHITE while charging, and the green LED will appear when fast charging is active.
- The indicators will turn off once the power bank is depleted.
- The power bank will automatically shut off after 32 seconds of inactivity, or you can press the ON/OFF button twice to turn it OFF manually.
- Disconnect your device once it is fully charged.

3. Wireless Charging Devices:

- Place your wireless charging device on the wireless charging surface(4).
- The device will begin to charging immediately and the wireless charging LED will glow BLUE, and the green LED will appear when fast charging is active.
- Once fully charged, remove the device.
- ** If your phone/device supports fast charging, the LED will glow BLUE & GREEN at the same time when wireless charging.

4. Wireless Charging with Magnetic Surface:

- If your phone supports MagSafe, it will securely align with the magnetic charging surface(4).
- The magnetic surface is compatible with other devices, but the magnetic alignment feature will only work with MagSafe-type phones.
- ** Note: When wireless charging, if the LED indicator is flashing BLUE the device is either NOT a wireless charging device or there is an object between the device and charging surface interfering with the charging process.

5. Built-in Powerbank Stand(5):

- Fold out the built-in stand on the back of the power bank to prop it up on a flat surface.

Safety Precautions:

WARNING-When using this product, basic precautions should always be followed:

1. Read all the instructions before use.
2. Charge the power bank fully before initial use. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified.
7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
8. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury.
9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 212°F may cause explosion.
10. Have servicing performed by a qualified repair person using only identical replacement parts.
11. This will ensure that the safety of the product is maintained.
12. Do not overcharge Phone. Unit may get hot with excessive use. Remove Phone when it is fully charged. Never charge for more than 7 hours at a time.
13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.
14. The strong magnetic fields of neodymium Magnets can damage items such as television, Computer monitors, credit cards, bank cards, Computers, diskettes and other data carriers, Video tapes, mechanical watches, hearing aid, loud speakers and VCRs. Pace-makers may be Damaged or switched to "test mode" in the presence of a strong magnetic force, if pacemaker or other electronical body implant is in use, keep a minimum of 3 feet distance.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful

interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-3 (B) / NMB-3(B)

This Class B digital apparatus complies with Canadian ICES-003.

(Cet appareil numérique de la Classe B conforme à la norme NMB-003 du Canada).

Name of the Distributor:

Leedsworld Inc

Address of the Distributor:

**400 Hunt Valley Road,
New Kensington,**

PA 15068 USA.

FCC ID: 2A92I-AST-WR410

Model AST-WR410

Made in China

